

SSH : ssh **arduino@sarath.local**

Bridges serial port data (from the Arduino/UNO Q) to a local TCP port (7500)

sudo socat -d -d file:/dev/ttyGS0,raw,echo=0,b9600,crtscts=0 tcp:127.0.0.1:7500

Tests the local TCP stream to verify that LoRa sensor data packets are arriving on port 7500

nc 127.0.0.1 7500

Builds a new local Docker image from your project files, tagged as latest

docker build -t sarath8078/cyber-console:latest .

Uploads the newly built Docker image to your Docker Hub repository

docker push sarath8078/cyber-console:latest

Stops and removes the currently running container to free up the name and port

docker stop cyber-console && docker rm cyber-console

Downloads the latest version of your Docker image from Docker Hub

docker pull sarath8078/cyber-console:latest

Starts the container in detached mode (-d), sharing the host network (--network host)

so it can seamlessly connect to your local socat bridge on port 7500

docker run -d --network host --name cyber-console sarath8078/cyber-console:latest

Streams the real-time logs from your gateway container to monitor incoming data and app status

docker logs -f cyber-console