EMERGENCY CHECKLIST

FLY — NAVIGATE — COMUNICATE

ENGINE FAILURE DURING TAKEOFF

- THROTTLE..... IDLE
- BRAKES..... APPLY
- FLAPS…… RETRACT
- MIXTURE..... IDLE CUTOFF
- IGNITION SWITCH..... OFF
- ATC..... ADVISE

ENGINE FAILURE AFTER TAKEOFF

- AIRSPEED..... 70 (Flaps Up)
  ..... 65(Flaps Down)
- MIXTURE..... IDLE CUTOFF
- FUEL SHUTOFF VLV..... OFF (pull full out)
- IGNITION SWITCH..... OFF
- FLAPS..... AS REQUIRED
- ATC..... ADVISE
- MASTER SWITCH..... OFF

ENGINE FAILURE IN FLIGHT

- AIRSPEED..... 68 KTS
- FUEL SHUTOFF VLV..... ON (push full in)
- FUEL SELECTOR VLV..... BOTH
- AUX FUEL PUMP SWITCH…..ON
- MIXTURE..... RICH
- IGNITION.....BOTH (or START)
- AUX FUEL PUMP SWITCH…..ON
- ATC..... ADVISE
- TRANSPONDER.....7700
- LANDING SITE..... DETERMINE

LANDING WITHOUT ENGINE POWER

- AIRSPEED..... 70 (Flaps Up)
  ..... 65(Flaps Down)
- MIXTURE..... IDLE CUTOFF
- FUEL SHUTOFF VLV..... OFF (pull full out)
- IGNITION SWITCH..... OFF
- FLAPS..... AS REQUIRED

Below 500 Feet:

- MASTER SWITCH..... OFF
- DOORS..... UNLATCH
- TOUCHDOWN.....SLIGHTLY TAIL LOW

FLIGHT INTO ICING CONDITIONS

- PITOT HEAT.....ON
- CABIN HEAT.....ON
- HEADING &/OR ALTITUDE..... CHANGE
- ATC..... ADVISE

ENGINE FIRE

On Ground:

- CRANKING..... CONTINUE

If Engine Starts:

- POWER.....1800 RPM
- ENGINE.....SHUTDOWN

If engine fails to start:

- THROTTLE..... FULL OPEN
- MIXTURE..... IDLE CUTOFF
- CRANKING..... CONTINUE
- FUEL SHUTOFF VLV..... OFF (pull full out)
- AUX FUEL PUMP SWITCH.....OFF
- ENGINE..... SECURE
  - MASTER SWITCH..... OFF
  - IGNITION SWITCH..... OFF

In Flight :

- ATC ..... ADVISE
- MIXTURE.....IDLE CUTOFF
- FUEL SHUTOFF VLV..... OFF (pull full out)
- AUX FUEL PUMP SWITCH..... OFF
- MASTER SWITCH.....OFF
- CABIN HEAT AND AIR..... OFF
- AIRSPEED.....100 KIAS
- LANDING WITHOUT ENGINE…... ACCOMPLISH

ELECTRICAL FIRE

- MASTER SWITCH.....OFF
- VENTS / CABIN AIR / HEAT.....CLOSED
- ALL ELECTRICAL SWITCHES.....OFF

If fire appears out and electrics needed:

- MASTER SWITCH.....ON
- CIRCUIT BREAKERS..... CHECK
- ELECTRICAL SWITCHES..... 1 AT TIME

- ATC..... ADVISE

AIRSPEEDS FOR EMERGENCY OPS

ENGINE FAILURE AFTER TAKEOFF:
- FLAPS UP.....70 KIAS
- FLAPS DOWN .....65 KIAS

MANEUVERING SPEEDS:
- 2550 Lbs.....105 KIAS
- 2200 Lbs.....98 KIAS
- 1900 Lbs.....90 KIAS

MAXIMUM GLIDE.....68 KIAS

Precautionary Landing with Engine.....65 KIAS

LANDING WITHOUT ENGINE POWER:
- FLAPS UP.....70 KIAS
- FLAPS DOWN .....65 KIAS