



NOT TO SCALE

PCB will rest on 4 #4-40 0.25" tall swage standoffs. P/N is TBD. And be held down with #4 5/8" screw. OD of standoffs is 0.25"

