g. Move the un-clipped Project Base Point to the SFO-B Origin Marker. Ensure you are snapping to the center.

