g. Verify the coordinate system alignment of the IFC model and the attributes of spaces in an IFC model viewer (e.g. Solibri or BIM Vision):

