- g. <u>Security Class</u>: The airport is separated into multiple layers of security. Every space within the airport is classified by the level of security maintained within that area. The adjacencies of two different security zones needs to be fully understood in order to facilitate security services. Every space therefore needs to have an associated security class. Where attributes are used in the generation of project documentation, the attribute will be SFO_SecurityClass. The security classes are defined as follows:
 - a. <u>Pre-Security</u>
 - b. Post-Security I
 - c. Post-Security II
 - d. Post-Security III
 - e. <u>Post-Security IV</u>