PART V: AREA DESIGNATOR

AA#.##A.##

For buildings with larger footprints it may be necessary to subdivide the drawing set into area designations. In these cases, a letter suffix is required to indicate the area of the plan each sheet represents. Every project where an area designation is utilized must include a key plan in the title block to orient the viewer as to where the specific area is located.

In the event that a project has in excess of 26 zones, the area designator can be a double alpha symbol. AA#.##AA.## In this case, the first zone is AA. When AZ is reached, the sequence begins again with BA, BB and so on.

For projects that are solely site and civil work where a floor designation is not needed, projects may resort to a two digit numeric zone system and omit the floor designation entirely. AA#.##.##

N.a	2	3	4	5	6	7	8	9	10	11	12	13	14
28	27	26	25	24	23	22	21	20	19	18	17	16	15
29	30	31	32	33	34	35	36	37	38	39	40	41	42
	55	54	53	52	51	50	49	48	47	46	45	44	43

Sample of numeric number layout for taxiway project

Sample of title block with key plan

