### 6.2.5    Global Parameters

Global parameters are specific to a single Revit project, but are not assigned to categories like project parameters.  Global parameters can be simple values, values derived from equations, or values taken from other global parameters.