m. Verify the Coordinate System alignment of the DWG by starting a line in AutoCAD at 0,0:

