Definitions

- a. Occupant Class: The most general designation of the use classification of a space type. This designation should be found in schedules and is used in the GIS platform for understanding the classification of the occupant of any given space. This information may change over the life of a space and may not be readily available during design and construction. Where attributes are used in the generation of project documentation, the attribute will be SFO OccupantClass. These categories will be limited to:
 - a. Airline Leasable | Cat I
 - b. Airline Leasable | Cat II
 - c. Airline Leasable | Cat III
 - d. Airline Leasable | Cat IV
 - e. Airline Leasable | Cat V
 - f. Airline Leasable | Other
 - g. Airport
 - h. Concession | Cat I
 - i. Concession | Cat 2
 - j. Concession | Cat 3
 - k. Concession | Cat 4
 - | Concession | Other
 - m. Government
 - n. **Unassigned**