d. Under modify setup/ general, use IFC4 Reference View as IFC version, 1st Level as space boundaries, and current shared coordinates as Project Origin:

