6.2.3 Family Parameters

Family parameters are only contained within a Revit family and can be used to control variables or values of the family. Family parameters can also be used to control a parameter in a nested family by associating the parameter in the host family to the parameter in the nested family.