

SOP-21 Pump Mechanical Seal Replacement (Rev 3)

Standard Operating Procedure - Prayag Petro Refinery - Unit 2

Prayag Petro Refinery - Unit 2

1. Scope

Feed charge pumps P-101A and P-101B mechanical seals

2. Applicable Equipment

P-101A, P-101B

3. Referenced Standards

OISD-STD-105 clause 5.1

4. Procedure

1. Apply LOTO per SOP-09 and confirm zero energy.
2. Drain and depressurise pump casing.
3. Remove coupling, back-pull assembly, extract worn mechanical seal.
4. Fit new seal; check DE/NDE bearing condition and shaft run-out.
5. Re-align pump to driver and record vibration on restart.