L1-M3 · L1-M4

E-stop and unexpected behaviour

What to do when something is not right

1. **E-stop works in every mode**
   In manual and autonomous mode alike, it takes priority and halts all operation.

2. **Manual override is not a bypass**
   It never switches off the safety systems. It is for setup, clearing a blocked path and tests after maintenance.

3. **Something unexpected?**
   MoRo moves somewhere new, or stops for no clear reason.

4. **Any immediate concern: press E-stop**
   Then report it. Diagnosing is not the operator's job at this level. Report early, even if it turns out minor.

When in doubt, stop it and report it.