TI MCU, DSP 및 Xilinx FPGA 프로그래밍 전문가 과정

Innova Lee(이상훈) gcccompil3r@gmail.com

Audio Signal Processing

Faust

Functional Audio Stream 의 약자

Real-Time Signal Processing 과 Synthesis 를 위해 특별히 고안된 함수형 프로그래밍 언어다.


개발 자체는 프랑스에서 진행되었다. 그래서 공식 홈페이지는 아래와 같이 프랑스 사이트에 있는 것을 볼 수 있다.

http://faust.grame.fr/




공식 홈페이지에서 Compiler 를 누른다.


아래 그림의 위치에 Compiler 가 보일 것이다.



누르면 아래와 같이 Online Compiler 가 활성화 된다.




여기서 Faust Online Compiler 를 누르면 아래와 같은 창이 나타난다.




맨 위의 점선은 사용자가 작성한 Faust 코드 파일을 드래그 앤 드롭으로 불러오는 상자다.


Faust Code 는 FAUST 에서 사용할 수 있는 코드를 입력하는 창이다. Compiled Code 는 작성한 FAUST Code 를 다른 언어로 변환시켜준다.



Diagrams 에 있는 Download Figure 를 누르면 현재 보이는 그림 파일을 내려 받을 수 있다. 해당 압축 파일은 프로젝트 폴더 내부에 process.svg 로 저장 된다.




Automatic Doc 는 현재 작성된 프로세스의 수학적 정의, 블록 다이어 그램, 파우스트 코드가 작성된 pdf 가 작성되며 Get the Documentation 을 누르면 해당 pdf 를 받을 수 있다.



Exec File 에서는 원하는 Target 으로 실행 파일을 만들 수 있다. QR 코드를 통해 내려받거나 실행시켜 결과를 확인 할 수 있다.

				Drop your .dsp f
Faust Code	Compiled Code	Diagrams	Automatic Doc	Exec File
Name Langu myFaustPrograr c		osc		
Please, select an architecture in the architeture menu.				

Architecture 를 Web, audio 로 설정하도록 한다.



Web 의 번거로움과 컴파일 타임을 고려하여 Setup 형태로 활용할 수도 있다. 공식 홈페이지에서 Donwload 로 가보자!

Faust Programming Language

About Compiler Documentation Download Editor Examples GitHub Proj

Download

The Faust compiler

The Faust compiler is available as a Faust github project with backends for C++, C, JAVA, JavaScrip ASM JavaScript, LLVM IR, WebAssembly and Interpreter. It has dependencies, in particular LLVM at libmicrohttpd. The LLVM backend is needed to compile FaustLive and other projects using the Iibfaust embedded Faust compiler.

You can also clone the github repository with the following command:

git clone git@github.com:grame-cncm/faust.git faust

Faust is easy to compile and to run on Mac and Linux. For Windows users we recommend to use FaustLive.

FaustLive for Windows 혹은 FaustLive for Ubuntu 를 선택하도록 한다.

FaustLive

FaustLive is the recommended tool to get started with Faust. Thanks to i FaustLive provides an ultra-short *edit-compile-run* cycle. Moreover Faus doesn't require any additional compiler or development tool (beside a sir

- FaustLive for Windows
- FaustLive for Windows+JACK
- FaustLive for OSX
- FaustLive for Ubuntu
- FaustLive sources (for Linux or Mac)


FaustLive demo

Here is a short video explaining the main characteristics of the FaustLive



For Windows

FaustLive for Windows 의 경우에는 아래와 같이 나타난다.



STEP 1 : Configure File Associations

Why would you do that?

To ensure that your system is well configured for .dsp, .lib and .svg and doesn't go crazy when FaustLive tries to open this kind of files.

- 1- Go to the folder « FilesToConfigure »
- 2- For each file:
 - a. Right Click on the file
 - b. Choose « Open With »
 - c. Check « Use this application for all »
 - d. Choose the default application with which the file will be opened

 (a text editor for .dsp and .lib ;
 a browser for .svg)


STEP 2 : Install JACK2

The latest release is available at: http://jackaudio.org/downloads/


STEP 3: Use FaustLive


- 1- Got to the Folder « FaustLive »
- 2- Launch the installer « setup_FaustLive »
- 3- Start using it =)


READ_ME_BEFORE_YOU_START 를 한 번 읽어보자 ~





내용을 읽어보니 JACK Audio 라는 것을 설치해야 한다. 편의를 위해 FAUST + JACK 으로 다운로드 받도록 한다.




























Downloading JACK

Linux

JACK1:

- Binaries: please use your distribution's package manager (apt-get, yum, synaptic etc.)
- Source tarball: JACK 0.125.0.

JACK2:

• Binaries: please use your distribution's package manager

Windows

JACK2:


• 32 bit installer: JACK 1.9.11.

• **64** bit installer: JACK 1.9.11.

Source tarball: JACK 1.9.12.

JACK Source Code Repository

JACK uses Git as its source control system. Our central git repository is hosted by Github. We are currently working toward linking the repositories for Jack1 and Jack2 but this work is not complete, so for now the commands to get a copy of the source are a little different depending on which tree/version you want.







Readme


Please read the following information.




X














?






WELCOME TO FAUSTLIVE

Dynamic Faust Compiler





Cancel


Version 2,44 by GRAME, Centre de Creation Musicale






WELCOME TO FAUSTLIVE

Dynamic Faust Compiler






Cancel

Version 2,44 by GRAME, Centre de Creation Musicale


For Linux



Advertisement - Report

```
🔘 🖨 🔳 sdr@sdr-Z20NH-AS51B5U: ~/audio/FaustLive-ubuntu-x86 64-2.43
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86 64-2.43/FaustLive$ ls
FaustLive
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86_64-2.43/FaustLive$ cd ...
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86_64-2.43$ ls
Documentation FaustLive FilesToConfigure READ ME BEFORE YOU START.pdf
                                                                      Whats New.pdf
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86_64-2.43$ nautilus ./
(nautilus:1310): GLib-( 🙉 🖨 🗊 FaustLive-ubuntu-x86_64-2.43
                                                                                                    coi
ections != NULL' failed
                                                                                        Q
                               噩
(nautilus:1310): GLib-(
                                                                                                    COI
ections != NULL' failed
                      (nautilus:1310): Gtk-CF
                                                                                                    \mathsf{ed}
                      Documentation
                                                                              FilesToConfigure
                                                                FaustLive
(nautilus:1310): GLib-(
                      Desktop
(nautilus:1310): GLib-(
                      n Documents
ce)' failed
                       Downloads
sdr@sdr-Z20NH-AS51B5U:~
                                                             Whats New.pdf
                                               READ ME
                      Music
                                             BEFORE YOU
                                               START.pdf
                       Pictures
                      Wideos
                         Trash
                      시스템 예약
                        251 GB Volume
                         Computer
```

```
sdr@sdr-Z20NH-AS51B5U: ~/audio
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86_64-2.43/FaustLive$ cd ...
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86 64-2.43$ ls
Documentation FaustLive FilesToConfigure READ ME BEFORE YOU START.pdf Whats New.pdf
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86 64-2.43$ nautilus ./
(nautilus:1310): GLib-GIO-CRITICAL **: q dbus interface skeleton unexport: assertion 'interface ->priv->conn
ections != NULL' failed
(nautilus:1310): GLib-GIO-CRITICAL **: q dbus interface skeleton unexport: assertion 'interface ->priv->conn
ections != NULL' failed
(nautilus:1310): Gtk-CRITICAL **: gtk icon theme get for screen: assertion 'GDK IS SCREEN (screen)' failed
(nautilus:1310): GLib-GObject-WARNING **: invalid (NULL) pointer instance
(nautilus:1310): GLib-GObject-CRITICAL **: g signal connect object: assertion 'G TYPE CHECK INSTANCE (instan
ce)' failed
sdr@sdr-Z20NH-AS51B5U:~/audio/FaustLive-ubuntu-x86 64-2.43$ cd ..
sdr@sdr-Z20NH-AS51B5U:~/audio$ sudo apt-get install jackd2
jackd2
                jackd2-firewire
sdr@sdr-Z20NH-AS51B5U:~/audio$ sudo apt-get install jackd2
[sudo] password for sdr:
Reading package lists... Done
Building dependency tree
Reading state information... Done
The following packages were automatically installed and are no longer required:
  linux-headers-4.10.0-28 linux-headers-4.10.0-28-generic linux-headers-4.13.0-45
 linux-headers-4.13.0-45-generic linux-headers-4.15.0-29 linux-headers-4.15.0-29-generic
 linux-headers-4.15.0-30 linux-headers-4.15.0-30-generic linux-headers-4.15.0-32
 linux-headers-4.15.0-32-generic linux-headers-4.15.0-33 linux-headers-4.15.0-33-generic
 linux-image-4.10.0-28-generic linux-image-4.13.0-45-generic linux-image-4.15.0-29-generic
 linux-image-4.15.0-30-generic linux-image-4.15.0-32-generic linux-image-4.15.0-33-generic
 linux-image-extra-4.10.0-28-generic linux-image-extra-4.13.0-45-generic linux-modules-4.15.0-29-generic
 linux-modules-4.15.0-30-generic linux-modules-4.15.0-32-generic linux-modules-4.15.0-33-generic
Use 'sudo apt autoremove' to remove them.
The following additional packages will be installed:
  jackd jackd2-firewire libconfig++9v5 libffado2 libgt5x11extras5 libxml++2.6-2v5 python-dbus python-gi
 qjackctl
Suggested packages:
 jack-tools meterbridge python-dbus-doc python-dbus-dbg python-gi-cairo
The following NEW packages will be installed:
  jackd jackd2 jackd2-firewire libconfig++9v5 libffado2 libqt5x11extras5 libxml++2.6-2v5 python-dbus
  python-qi qjackctl
O upgraded, 10 newly installed, O to remove and 253 not upgraded.
Need to get 2,571 kB of archives.
After this operation, 11.7 MB of additional disk space will be used.
Do you want to continue? [Y/n] y
```



If you want to run jackd with realtime priorities, the user starting jackd needs realtime permissions. Accept this option to create the file /etc/security/limits.d/audio.conf, granting realtime priority and memlock privileges to the audio group.

Running jackd with realtime priority minimizes latency, but may lead to complete system lock-ups by requesting all the available physical system memory, which is unacceptable in multi-user environments.

Configuring jackd2

Enable realtime process priority?

<Yes>

<No>

🔘 🖨 🗊 sdr@sdr-Z20NH-AS51B5U: ~/audio/FaustLive-ubuntu-x86 64-2.43/FaustLive Cannot create RT messagebuffer thread: Operation not permitted (1) Retrying messagebuffer thread without RT scheduling Messagebuffer not realtime; consider enabling RT scheduling for user no message buffer overruns Cannot create RT messagebuffer thread: Operation not permitted (1) Retrying messagebuffer thread without RT scheduling Messagebuffer not realtime; consider enab 🔕 🖯 🗈 FLW-1:BlowBottle no message buffer overruns Cannot create RT messagebuffer thread: Ope > Parameters Retrying messagebuffer thread without RT Messagebuffer not realtime; consider enab Basic_Parameters no message buffer overruns JACK server starting in realtime mode with freq gain self-connect-mode is "Don't restrict self gate Cannot lock down 82274202 byte memory area 440Hz 1.00 audio reservation init Acquire audio card Audio0 Envelopes_and_Vibrato creating alsa driver ... hw:0|hw:0|1024|2 Envelope_Parameters Vibrato_Parameters configuring for 48000Hz, period = 1024 fra ALSA: final selected sample format for cap Envelope_Attack Vibrato_Attack ALSA: use 2 periods for capture ALSA: final selected sample format for pla 0.50s ALSA: use 2 periods for playback Cannot use real-time scheduling (RR/10)(1 0.01sne. Vibrato_Begin AcquireSelfRealTime error Cannot lock down 82274202 byte memory area The sample rate is now 48000/sec 0.05s Git Larg Envelope_Decay physical input system:capture 1 physical input system:capture 2 Vibrato_Freq physical output system:playback 1 s larger physical output system:playback 2 physical output system:playback 3 : warning: File dsp proj bak/output.avi is 58.75 MB; this is larger physical output system:playback 4 s recommended maximum file size of 50.00 MB physical output system:playback 5 physical output system:playback_6 physical output system:playback 7 physical output system:playback_8 SET DSP = BlowBottle The buffer size is now 1024/sec Cannot use real-time scheduling (RR/5)(1: Operation not permitted) JackClient::AcquireSelfRealTime error Destination port in attempted (dis)connection of FLW-1:BlowBottle Out 0 and system:capture 1 is not an input Destination port in attempted (dis)connection of FLW-1:BlowBottle_Out_1 and system:capture_2 is not an input port OInotifyFileSystemWatcherEngine::addPaths: inotify add watch failed: No such file or directory