

Switches

1. Master Switch – Control All

- Control Master relay and section relays.

2. Master Switch – Master Relay only

- Control Master relay

3. Master Switch – Master Override

- Master Switch is always on.

4. Work Switch

- Use a switch connected to the implement to control On/Off.

5. Auto Switch – Rate

- Auto rate control.

6. Auto Switch – Sections

- Auto section control.

7. On-Screen Switches – Enabled

- Show on-screen switches.

8. On-Screen Switches – Dual Auto

- Show auto rate button and auto section button.