## **Pressure**

Take two readings to calibrate. Set to a known minimum pressure and enter the reading and the pressure. Do the same for a known maximum pressure.

Press show to display the pressure screen.