- 1. Reset relays (circle)
- 2. Renumber sections (+)
- 3. Relay Types
  - a. Section Relay controlled by section switch
  - b. Slave Relay is on when any section relay is on and off

when all section relays are off.

c. Master - Relay is on when any section relay is on and

turns off before section relays turn off. Section

relays remain in their same state.

d. Power - Relay is on all the time.

- e. Invert Section Relay is on when section is off.
- f. Hyd Up
- g. Hyd Down
- h. Tram Right
- i. Tram Left
- j. Geo Stop
- 4. Section # The section that controls the relay.