Network

- 1. Rescan (circle)
- 2. Send subnet address to modules (up arrow)

The default values for each board can be loaded into settings.