

Products – Rate

Menu: Products > Rate

Configures the fundamental properties of a product.

Setting	Description
1. Product Name	Name of the product
2. Control Type	How the application rate is controlled (see below)
3. Quantity Units	Units used to measure the product (L, gal, kg, lbs, seeds, etc.)
4. Coverage Units	Acre, Hectare, Minute, or Hour
5. Sensor Counts/Unit	Number of sensor pulses per unit of product applied
6. Density	Product density (used for mass/volume conversion)
7. Base Rate	Target application rate
8. Alt. Rate (%)	Alternate rate as a percentage of the base rate
9. Tank Size	Total tank capacity

Control Types

Selects the actuator driving the product and how the PID loop positions it. This must match the physical valve/motor wiring on the module — an incorrect selection can leave the actuator open or unresponsive.

Type	Description
Standard Valve	A proportional flow-control valve driven continuously by the PID loop — includes a motorized ball valve or a solenoid valve. PWM = 0 stops the valve motor and holds its last position (does not drive it closed) — use this for valves with no dedicated closed/shutoff position.
Combo Close	Same continuous PID control as Standard Valve — includes a motorized ball valve or a solenoid valve — but the valve is also driven fully closed whenever the product/section is off (rather than just holding position). Use for valves that must shut off flow, not just stop adjusting.
Motor	Drives a variable-speed motor that IS the metering device itself (e.g. a hydraulic or electric drive motor turning a metering roller/auger/pump) — not a motorized valve. PID output accumulates over time (integrating control) instead of positioning directly, so it needs different gain tuning than a valve.
Combo Timed	For close-only/on-off style valves that can't be positioned proportionally. Instead of continuous PWM, the valve is pulsed through alternating Adjust/Pause cycles (set on the Control page) to work the rate toward target, with a fast minimum-start ramp from zero.

Controls

Control	Action
 Navigate left	Previous product
 Navigate right	Next product
 Cancel	Discard changes
 Save	Save settings

Products – Mode

Menu: Products > Mode

Sets the operating mode for each product. Navigate between products with the left/right arrows.

Mode	Description
Controlled UPM	PID feedback control — adjusts motor/valve to maintain the target rate as speed changes
Constant UPM	Maintains a fixed flow rate based on total machine width regardless of which sections are on. Used for sprayers where turned-off sections return flow to the tank (after the flow meter). RC corrects the measured flow by subtracting the estimated contribution of the off sections to give an accurate application rate per acre/hectare.
Document Applied	Tracks and records material that has already been applied — no active control
Document Target	Tracks and records the target rate for comparison — no active control

Controls

Control	Action
 Navigate left	Previous product
 Navigate right	Next product
 Cancel	Discard changes
 Save	Save settings