

Products – Rate

Menu: Products > Rate

Configures the fundamental properties of a product.

Setting	Description
1. Product Name	Name of the product
2. Control Type	How the application rate is controlled (see below)
3. Quantity Units	Units used to measure the product (L, gal, kg, lbs, seeds, etc.)
4. Coverage Units	Acre, Hectare, Minute, or Hour
5. Sensor Counts/Unit	Number of sensor pulses per unit of product applied
6. Density	Product density (used for mass/volume conversion)
7. Base Rate	Target application rate
8. Alt. Rate (%)	Alternate rate as a percentage of the base rate
9. Tank Size	Total tank capacity

Control Types

Selects the actuator driving the product and how the PID loop positions it. This must match the physical valve/motor wiring on the module — an incorrect selection can leave the actuator open or unresponsive.

Type	Description
Standard Valve	A proportional flow-control valve driven continuously by the PID loop — includes a motorized ball valve or a solenoid valve. PWM = 0 stops the valve motor and holds its last position (does not drive it closed) — use this for valves with no dedicated closed/shutoff position.
Combo Close	Same continuous PID control as Standard Valve — includes a motorized ball valve or a solenoid valve — but the valve is also driven fully closed whenever the product/section is off (rather than just holding position). Use for valves that must shut off flow, not just stop adjusting.
Motor	Drives a variable-speed motor that IS the metering device itself (e.g. a hydraulic or electric drive motor turning a metering roller/auger/pump) — not a motorized valve. PID output accumulates over time (integrating control) instead of positioning directly, so it needs different gain tuning than a valve.
Combo Timed	For close-only/on-off style valves that can't be positioned proportionally. Instead of continuous PWM, the valve is pulsed through alternating Adjust/Pause cycles (set on the Control page) to work the rate toward target, with a fast minimum-start ramp from zero.

Fans

The last two products in the list are fans, named Fan 1 and Fan 2. Selecting one replaces the product settings with the fan settings, because a fan is controlled to a speed rather than to an application rate.

Setting	Description
Sensor Counts / RPM	Number of sensor pulses per revolution
Target RPM	The speed the fan is controlled to
Current RPM	Measured fan speed (read-only)
Error %	How far the measured speed sits from the target, as a percentage (read-only)
Fan Display	Opens a floating window showing this fan's speed (see below)

Fan Display Window

Show opens a floating window with the live speed of that fan. Press Save to apply it. Each fan has its own button and its own window, so both can be on screen at once; each window is labelled with the fan it belongs to. The windows have no title bar and use the display colours set under Options.

A window follows the main screen when the main screen is moved, as long as the two overlap. **Click and drag** it (either mouse button) to reposition it; drag it clear of the main screen and it stops following. It detaches while the main screen is minimized and re-attaches when the main screen is restored. Each window's position is remembered separately between sessions.

A fan that is not enabled (Products > Settings) has no display window, whatever this button is set to, and enabling the fan again brings its window back.

Controls

Control	Action
 Navigate left	Previous product
 Navigate right	Next product
 Cancel	Discard changes
 Save	Save settings