

Products – Mode

Menu: Products > Mode

Sets the operating mode for each product. Navigate between products with the left/right arrows.

Mode	Description
1. Section controlled UPM	PID feedback control — adjusts motor/valve to maintain the target rate as speed changes. Flow varies with the number of sections on (on/off valves).
2. Constant UPM	Maintains a fixed flow rate based on total machine width regardless of which sections are on. Used for sprayers where turned-off sections return flow to the tank (after the flow meter) — metered bypass valves. RC corrects the measured flow by subtracting the estimated contribution of the off sections to give an accurate application rate per acre/hectare.
3. Document applied	Tracks and records material that has already been applied — no active control.
4. Document target rate	Tracks and records the target rate for comparison — no active control, no module.
5. Document applied manual rate	For implements with a fixed mechanical/manual metering that has no flow sensor or module at all (e.g. a fertilizer spreader gate set to a position). Enter the flow rate the implement is putting out, in units per minute , in the Manual Rate box below. RC computes the displayed and logged application rate from that fixed value and ground speed — the same way Constant UPM computes rate, substituting the typed value for a real sensor's reading. No active control, no module.

Manual Rate

Only enabled when Mode 5 is selected. Enter the implement's measured output in units per minute — **not** per acre/hectare. This is typically found by running the implement at its set gate/metering position and weighing or measuring output over a timed interval.

Note: Because the entered value is a constant flow, not a per-area rate, the displayed/logged application rate will rise and fall with ground speed even though nothing on the implement has changed — slower ground speed covers less area per minute for the same flow, so the rate per acre/hectare goes up, and vice versa. This is expected for a fixed-metering implement.

Controls

Control	Action
 Navigate left	Previous product
 Navigate right	Next product
 Cancel	Discard changes
 Save	Save settings