

Machine – Relays

Menu: Machine > Relays

Assigns relay functions to each relay output on the module. There are **16 relays per module** and up to **8 modules**.

Control	Action
 Reset (circle)	Reset all relays to default
 Renummer (+)	Renummer sections sequentially
Relay Number	The relay output number
Relay Type	The behavior of the relay (see below)
Number	For Switch type: switch number. For Section/Invert_Section type: section number.
 Cancel	Discard changes
 Save	Save settings

Application Control

Spraying occurs when:

- Master is ON
- A section is enabled
- In Auto, the guidance system allows application

Relay Types

Type	Description
Section	Controls an individual section. In Manual, the switch turns the section on or off. In Auto, the guidance system controls the section, but the switch can disable it.
Invert_Section	Opposite of the Section output (on when the section is off).
Slave	On when any section is on; off when all sections are off.
Bypass	On when all sections are off; off when any section is on.
FlowMaster	Controls overall product flow. In Manual, it follows the Master switch. In Auto, it is on only when the Master switch is on and the machine is moving. Use this to control overall product flow through an upstream valve or common shutoff.
Invert_FlowMaster	Opposite of the FlowMaster output (on when the FlowMaster output is off).
Master	Follows the Master switch. Use this when a relay should follow the master logic itself rather than actual flow-enabled status.
Invert_Master	Opposite of the Master output (on when the Master output is off).
Power	Always on.
Switch	Controlled directly by a switch (not affected by Master or Auto).
Hyd Up	Hydraulic raise.
Hyd Down	Hydraulic lower.
Tram Right	Tram marker right.
Tram Left	Tram marker left.
Geo Stop	Geofence stop output.
None	No function assigned to the relay.

FlowMaster Valve Options

These options apply only when exactly one **FlowMaster** relay is defined on the selected module.

Option	Description
2-wire valve (requires module support)	Uses one FlowMaster relay and requires module support to treat that relay as a 2-wire valve control. In this setup, the module uses the single FlowMaster relay definition to generate opposite open and close signals for a 2-wire motorized valve.
2-wire valve + Invert_FlowMaster	Uses two normal relay outputs: one FlowMaster relay and one Invert_FlowMaster relay. Use this for generic relay hardware when a valve needs separate open and close signals.
3-wire valve	Uses one normal FlowMaster relay output for a simple on/off valve or a valve with its own internal open/close handling.