Installation Sheet — Model 1575NR

Model 1575NR is a 1½" NPSH combination fog / straight-stream nozzle. Follow these steps to fit it to your hose. Installation should be carried out by a qualified person in accordance with local fire codes and the authority having jurisdiction.



1. **Shut off the water supply**
   Make sure the hose is uncharged and the supply valve is fully closed before fitting the nozzle.

2. **Inspect the nozzle and coupling**
   Check that the 1½" NPSH threads on the nozzle and the hose coupling are clean and undamaged, and that the coupling gasket is present and in good condition.

3. **Thread the nozzle on**
   Align the nozzle inlet with the hose coupling and turn it clockwise by hand until it is snug. Do not cross-thread.

4. **Do not over-tighten**
   Hand-tight is sufficient. Avoid pipe wrenches or tools on the Lexan (polycarbonate) body.

5. **Set the nozzle to OFF**
   Turn the nozzle to the off position before charging the hose.

6. **Charge and check for leaks**
   Open the supply valve slowly. Check the connection for leaks and re-seat the gasket if needed. Operating pressure must not exceed 200 PSI.

7. **Test the stream**
   Briefly open the nozzle to confirm fog, straight stream and off positions work, then return to off.

IMPORTANT

- Maximum operating pressure: 200 PSI. Rated flow approx. 75 GPM @ 100 PSI.
- Use with water only. Do not use on damaged, cracked or deformed nozzles — replace them.
- Inspect and test the nozzle and hose station regularly, as required by local codes.

tesla fire systems inc.

Toronto — Head Office
1010 Bathurst St, Toronto, ON M5R 3G7
(416) 535-9693 | 1-866-471-2916
info@teslafiresystems.com

Vancouver (Office)
112-970 Burrard Street
Vancouver, BC V6Z 2R4
1-866-471-2916

Montreal (Office)
2001 Blvd Robert-Bourassa, 17th Floor
Montreal, QC H3A 2A6
1-866-471-2916