SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

iS7 75kW VFD (INV-LSLV0750-iS7) — Datasheet

1. Overview

High performance VFD 75kW, sensorless & sensored vector, built-in DC reactor. Product family: Variable frequency drives. Lifecycle status: **MATURE**.

2. Technical specifications

2.1. Ratings

Item	Value
Rated output (heavy duty)	75 kW / 150 A
Overload capacity (heavy duty)	150% for 1 minute

2.2. Performance and characteristics

Item	Value
Control method	V/F, sensorless vector, sensored vector (encoder option)

2.3. Endurance and communication

Item	Value
Communication options	Profibus-DP, EtherNet/IP, Modbus TCP, CANopen
Encoder option input	Line driver / open collector, up to 200 kHz

2.4. Protection and options

Item	Value
Built-in DC reactor	Yes

3. Installation data

3.1. Terminals

- Dimensions (W x H x D): 300 x 534 x 265 mm
- Weight: 42 kg
- Degree of protection: IP21
- Operating temperature: -10 to +50 °C

4. Standards and certifications

Applicable standards:

- IEC 61800-5-1
- IEC 61800-3

Certifications held:

- CE
- UL
- KC

Certificates and declarations of conformity are available from the Certification & Compliance team on request. Certifications not listed above are not held for this product; project-specific evaluation can be requested.

5. Ordering information

Item	Value
Ordering code	INV-LSLV0750-iS7
Standard lead time	6 weeks ex-works
Minimum order quantity	1
Warranty	24 months (see POL-WARRANTY)
Firmware	latest 4.10 (see RN-INV-LSLV0750-iS7)

6. Related documents

- IG-INV-LSLV0750-iS7 — Installation and Commissioning Guide
- TG-INV-LSLV0750-iS7 — Troubleshooting and Error Code Guide
- RN-INV-LSLV0750-iS7 — Firmware Release Notes
- FAQ-DRIVE — Variable frequency drives FAQ

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

iS7 75kW VFD (INV-LSLV0750-iS7) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: 100 mm above and below, 50 mm on each side; mount vertically for cooling airflow
- Operating temperature: -10 to +50 °C
- Degree of protection: IP21
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Enter motor nameplate data (rated power, current, voltage, frequency, speed)
2. Select command source and frequency reference
3. Perform auto-tuning (rotational if possible)
4. Set acceleration/deceleration times for the load
5. Test run at low speed and check rotation direction

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See
Over-current trip during acceleration	Acceleration time too short for load inertia	TG-INV-LSLV0750-iS7 §3.1
Over-current trip immediately at run command	Motor cable insulation breakdown (phase-to-phase short)	TG-INV-LSLV0750-iS7 §3.2
Over-current trip at restart after momentary power loss	Firmware defect in speed search at restart	TG-INV-LSLV0750-iS7 §3.4
Over-voltage trip during deceleration	Regenerative energy from load; deceleration time too short	TG-INV-LSLV0750-iS7 §3.5

On-site commissioning support can be requested through the Global CS Center. For variable frequency drives the request is handled by the technical support team.

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

iS7 75kW VFD (INV-LSLV0750-iS7) — Firmware Release Notes

1. Summary

Latest firmware: **4.10**. Updating to the latest version is recommended for all units.

2. Version history

2.1. Version 4.10 (2025-12-15)

- Fixed: EtherNet/IP option loses connection after 49.7 days uptime
- Added: cooling fan life warning

2.2. Version 4.05 (2025-03-10)

- Fixed: E.OC trip at restart after momentary power loss (speed search)

2.3. Version 4.00 (2024-08-19)

- Baseline release

3. Update procedure

1. Back up parameters / project before updating.
2. Connect the engineering tool (v4.6 or later).
3. Do not switch off power during the update.
4. After the update, verify the version and restore parameters if required.
5. If the update fails, do not power-cycle the unit repeatedly; contact support for the recovery procedure.

4. Compatibility

Parameter files from older versions can be loaded; files from newer versions cannot be loaded into older firmware.