SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

DIN Rail Energy Meter (METER-LPB-DIN) — Datasheet

1. Overview

DIN-rail direct-connected energy meter up to 80A, MID class B. Product family: Power & energy meters. Lifecycle status: **ACTIVE**.

2. Technical specifications

2.1. Ratings

Item	Value
Accuracy class	Class 1 (IEC 62053-21) / MID class B
Maximum current (direct connection)	80 A
Wiring	1P2W or 3P4W (model dependent)

2.3. Endurance and communication

Item	Value
Communication	Modbus RTU (RS-485)
Pulse output	Open collector, 1000 imp/kWh

3. Installation data

3.1. Terminals

- Dimensions (W x H x D): 72 x 90 x 66 (4 modules) mm
- Weight: 0.4 kg
- Degree of protection: IP51 (front)
- Operating temperature: -25 to +55 °C

4. Standards and certifications

Applicable standards:

- IEC 62053-21
- EN 50470-3

Certifications held:

- CE
- MID

Certificates and declarations of conformity are available from the Certification & Compliance team on request. Certifications not listed above are not held for this product; project-specific evaluation can be requested.

5. Ordering information

Item	Value
Ordering code	METER-LPB-DIN
Standard lead time	3 weeks ex-works
Minimum order quantity	10
Warranty	24 months (see POL-WARRANTY)
Firmware	not applicable

6. Related documents

- IG-METER-LPB-DIN — Installation and Commissioning Guide
- TG-METER-LPB-DIN — Troubleshooting and Error Code Guide
- MG-METER-LPB-DIN — Maintenance Guide
- FAQ-METER — Power & energy meters FAQ

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

DIN Rail Energy Meter (METER-LPB-DIN) — Installation and Commissioning Guide

1. Safety

Installation, wiring and commissioning must be performed by qualified personnel. Disconnect and lock out all power sources before work. Verify absence of voltage.

2. Receiving and storage

Inspect the packaging on arrival and report damage within 7 days (see POL-RETURN). Store indoors in a dry place between -25 and +55 °C, relative humidity below 85% without condensation.

3. Mounting and clearances

- Required clearances: Panel cut-out 92 x 92 mm (panel type) or 35 mm DIN rail
- Operating temperature: -25 to +55 °C
- Degree of protection: IP51 (front)
- Above 1,000 m altitude, apply derating per the datasheet.

4. Wiring and tightening torques

- Terminal tightening torque: see dimension drawing
- Use copper conductors rated for at least 75 °C.
- Separate power and signal cables by at least 200 mm.

5. Commissioning procedure

1. Check CT polarity and phase sequence
2. Set CT and VT ratios
3. Set communication address and baud rate
4. Verify readings against a reference meter

6. Pre-energisation checklist

☐ Product rating matches the drawing
☐ All terminals tightened to specified torque
☐ Protective earth connected
☐ Insulation resistance measured and recorded
☐ Settings / parameters recorded

7. Common commissioning issues

Symptom	Likely cause	See

Negative active power reading	CT polarity reversed	TG-METER-LPB-DIN §3.1
No Modbus response	Address / baud / parity mismatch	TG-METER-LPB-DIN §3.2
Pulse output not counted by PLC	Open-collector output polarity reversed	TG-METER-LPB-DIN §3.3

On-site commissioning support can be requested through the Global CS Center. For power & energy meters the request is handled by the technical support team.

SYNTHETIC DATA — 교육용 가상 데이터이며 실제 제품 사양·운영 기준과 무관합니다.

DIN Rail Energy Meter (METER-LPB-DIN) — Maintenance Guide

1. Maintenance intervals

Task	Interval
Accuracy check against reference	5 years
Terminal inspection	3 years

2. Spare parts

- No user-replaceable parts; replace the complete unit.

3. End of life

Lifecycle status: ACTIVE. Expected service life is 20 years under normal conditions. Dispose of according to local regulations for electrical equipment.