Cattle	Decadution
Setting	Description
② Flash compensation/output	The options available vary with flash control mode.  • TTL: Adjust flash compensation (the full value may not be applied if the limits of the flash control system are exceeded). In the cases of the EF-X20, EF-20, and EF-42, the selected value is added to the value selected with the flash unit.  • M/MULTI: Adjust flash output (compatible units only). Choose from values expressed as fractions of full power, from ½ (mode M) or ¼ (MULTI) down to ½12 in increments equivalent to ½ EV. The desired results may not be achieved at low values if they exceed the limits of the flash control system; take a test shot and check the results.
③ Flash mode (TTL)	Choose a flash mode for TTL flash control. The options available vary with the shooting mode ( <b>P</b> , <b>S</b> , <b>A</b> , or <b>M</b> ) selected.  • 知 ( <b>FLASH AUTO</b> ): The flash fires only as required; flash level is adjusted according to subject brightness. A class icon displayed when the shutter button is pressed halfway indicates that the flash will fire when the photo is taken.  • 知 ( <b>STANDARD</b> ): The flash fires with every shot if possible; flash level is adjusted according to subject brightness. The flash will not fire if not fully charged when the shutter is released.  • 知 ( <b>SLOW SYNC.</b> ): Combine the flash with slow shutter speeds when photographing portrait subjects against a backdrop of night scenery. The flash will not fire if not fully charged when the shutter is released.