
The Playback Display

This section lists the indicators that may be displayed during playback.

For illustrative purposes, displays are shown with all indicators lit.



| 1 Date and time40, 42, 201 | 16 White balance 110 |
|--|---|
| 2 Face detection indicator128 | 17 Sensitivity77 |
| 3 Bluetooth ON/OFF236 | 18 Exposure compensation81 |
| 4 Image transfer order191 | 19 Aperture57, 62, 63 |
| 5 Image transfer status236, 274 | 20 Shutter speed57, 58, 63 |
| 6 Number of frames selected for upload 191 | 21) Playback mode indicator47 |
| ? Frame number | 22 Movie icon53 |
| 8 Sound and flash indicator203 | 23 Time code |
| Protected image186 | 24 HDR image90 |
| 10 Location data241, 275 | 25) Red-eye removal indicator152, 188 |
| 105 Image quality | 26 Advanced filter97 |
| (12) Image size104 | 27 Gift image47 |
| 13 Film simulation106 | 28 Photobook assist indicator193 |
| 14 Dynamic range113 | 29 DPOF print indicator195 |
| 15 HDR90 | 30 Rating190 |
| | |