Assigning Roles to the Function Buttons

The roles played by the function buttons can be selected using the BUTTON/DIAL SETTING > FUNCTION (Fn) SETTING option in the setup menu.

- IMAGE SIZE
- IMAGE OUALITY
- RAW
- FILM SIMULATION
- GRAIN FFFFCT
- COLOR CHROME FEFECT
- COLOR CHROME EX BLUE
- DYNAMIC RANGE
- D RANGE PRIORITY
- WHITE BALANCE
- CLARITY
- SELECT CUSTOM SETTING
- FOCUS AREA
- FOCUS CHECK
- FOCUS MODE
- AF MODE
- AF-C CUSTOM SETTINGS
- FACE DETECTION ON/OFF
- AF RANGE LIMITER
- FOCUS CHECK LOCK
- SPORTS FINDER MODE
- PRE-SHOT **ES ₽**
- SFI F-TIMER
- AE BKT SETTING
- FOCUS BKT SETTING
- PHOTOMETRY
- SHUTTER TYPE
- FLICKER REDUCTION
- ISO
- IS MODE
- WIRFLESS COMMUNICATION
- FLASH COMPENSATION

- FLASH FUNCTION SETTING
- TTI-LOCK
- MODFLING FLASH
- MOVIE RECORDING RELEASE
- FULL HD HIGH SPEED REC
- FIX MOVIE CROP MAGNIFICATION 1.79x
- 7FBRA SETTING
 - INTERNAL/EXTERNAL MICLEVEL **ADJUSTMENT**
- MOVIF OPTIMIZED CONTROL
- VIFW MODE SETTING
- PREVIEW DEPTH OF FIELD
- PREVIEW FXP./WB IN MANUAL MODE
- NATURAL LIVE VIEW
- HISTOGRAM
 - FLECTRONIC LEVEL
 - I ARGE INDICATORS MODE
 - F-Log VIEW ASSIST
 - AE LOCK ONLY
- AF LOCK ONLY
- AF/AF LOCK
 - AF-ON
 - AWB LOCK ONLY
 - APERTURE SETTING
 - PERFORMANCE
 - AUTO IMAGE TRANSFER
- SELECT PAIRING DESTINATION
- Bluetooth ON/OFF
 - OUICK MENU
- PLAYBACK
- NONE



To disable the function button, choose **NONE**.