## Playback Touch Controls

When ON is selected for ■ BUTTON/DIAL SETTING > TOUCH SCREEN SETTING > TOUCH SCREEN SETTING, touch controls can be used for the following playback operations:

• **Swipe**: Swipe a finger across the display to view other images.



 Pinch-out: Place two fingers on the display and spread them apart to zoom in.



• **Pinch-in**: Place two fingers on the display and slide them together to zoom out.



- Pictures can be zoomed out until the entire image is visible but no further
- **Double-tap**: Tap the display twice to zoom in on the focus point.



• **Drag**: View other areas of the image during playback zoom.

