## CONSTANT SPEED ZOOM (Fn)

Choose the rate at which compatible power zoom lenses can be zoomed in or out using function buttons. The higher the number, the higher the rate.

Options								
1(SLOW)	2	3	4	5	6	7	8(FAST)	

## CONSTANT SPEED ZOOM/FOCUS (Fn) OPERATION

Choose whether the function buttons on compatible power zoom lenses need only be pressed once to start and stop power focus or power zoom.

Option	Description			
START/STOP	<b>START/STOP</b> The operation starts when the button is pressed and stops wh			
SWITCH	it is pressed a second time.			
<b>ACTIVE WHILE</b>	The operation continues while the button is pressed and stops			
PRESSING	when the button is released.			

## ZOOM RING ROTATE

Choose whether to reverse the rotation of the zoom ring on compatible power zoom lenses.

Options				
C CW (clockwise)	• CCW (counterclockwise)			

## ZOOM/FOCUS CONTROL RING

Choose role played by the zoom/focus control ring on compatible power zoom lenses.

Options					
ZOOM	FOCUS				