Before recording movies remotely, you will need to create a connection setting profile for use when connecting the camera to a computer or tablet via wireless or wired LAN.

- Connecting via Wireless LAN (📖 294)
- Connecting via Wired LAN (Ethernet) (📖 299)

Connecting via Wireless LAN

Create a connection setting profile for use when connecting the camera to a computer or tablet via wireless LAN.

1 Select **CREATE/EDIT CONNECTION SETTING** > **CREATE USING WIZARD** in the network/USB setting menu and choose **REMOTE REC FUNCTION**.

2 Select **CREATE NEW**.

  ◈ Choose **SELECT FROM LIST** to select from a list of existing connection setting profiles.

REMOTE REC FUNCTION

CREATE NEW
SELECT FROM LIST

CREATE NEW CONNECTION SETTING
USING WIZARD

3 Press **MENU/OK** when prompted.

1 ▸ 2 ▸ 3

SELECT COMM SETTING

SELECT COMM SETTING
TO USE THIS FUNCTION

NEXT   BACK

4 Select **WIRELESS LAN**.

SELECT COMM SETTING

WIRELESS LAN
WIRED LAN

CONNECT TO NETWORK
VIA WIRELESS LAN