## S.S. OPERATION

Select **OFF** to disable shutter-speed fine-tuning using the command dials.

Options	
ON	OFF

## COMMAND DIAL DIRECTION

Choose the direction in which the command dials are rotated to choose values. Settings for the front and rear command dials can be adjusted separately.

Option	Description
-↔+	Rotate the dial right for higher values or to move to the next
— <b>— T</b>	item.
+↔-	Rotate the dial left for higher values or to move to the next item.

## **SHUTTER AF**

Choose whether the camera focuses when the shutter button is pressed halfway.

Option	Description
AF-S	<ul> <li>ON: Focus locks when the shutter button is pressed halfway.</li> <li>OFF: No focus operation is performed when the shutter button is pressed halfway.</li> </ul>
AF-C	<ul> <li>ON: The camera focuses while the shutter button is pressed halfway.</li> <li>OFF: No focus operation is performed when the shutter button is pressed halfway.</li> </ul>