Editing Custom Settings

Edit existing custom settings banks.

- Navigate to MIMAGE QUALITY SETTING in the photo menus, highlight ■ EDIT/SAVE CUSTOM SETTING, and press MENU/OK.
- 2 Highlight the desired custom settings bank and press MENU/OK.



3 Highlight EDIT/CHECK and press MENU/OK.



4 The camera will display a list of shooting menu items; highlight an item you wish to edit and press MENU/OK. Adjust the selected item as desired.

