## **►** ISO BUTTON SETTING

Choose the role performed by the ISO button during playback.

Option	Description
MAKIPHUNE	Pressing the button marks the current picture for transfer. If the
	camera is not currently paired with a smartphone, <b>Bluetooth/</b>
	SMARTPHONE SETTING options will be displayed.
	Pressing the button displays a dialog where pictures can be
□□ SELECT &	selected for upload to a smartphone with which the camera
SMARTPHONE	is paired (🕮 237). If the camera is not currently paired with
TRANSFER ORDER	a smartphone, <b>Bluetooth/SMARTPHONE SETTING</b> options
	will be displayed instead (🗐 262).
	The button can be used for wireless connections.