
COLOR

Adjust color density. Choose higher values to increase saturation, lower values to reduce it.



SHARPNESS

Sharpen or soften outlines. Choose higher values for sharper outlines, lower values for softer outlines.



NOISE REDUCTION

Reduce noise in pictures taken at high sensitivities. Choose higher values to reduce noise and smooth outlines, lower values to leave outlines visible.

Options								
-4	-3	-2	-1	0	+1	+2	+3	+4