Problem	Solution
No panorama is recorded when the shutter button is pressed.	The indicator lamp was orange when you attempted to record a panorama: Wait until the indicator lamps turns off (8).
No face is detected.	The subject's face is obscured by sunglasses, a hat, long hair, or other objects: Remove the obstructions (■ 156). The subject's face occupies only a small area of the frame: Change the composition so that the subject's face occupies a larger area of the frame (■ 156). The subject's face is turned away from the camera: Ask the subject to face the camera (■ 156). Face/Eye detection setting is off: Turn Face/Eye DETECTION SETTING on (■ 156). The camera is tilted: Keep the camera level. The subject's face is poorly lit: Shoot in better light.
No subject is detected.	The subject is partially hidden: Choose a vantage point where you can see as much of the subject as possible (■ 158). The subject occupies only a small portion of the frame: Get closer to your subject so it occupies more of the frame (■ 158). OFF is selected for SUBJECT DETECTION SETTING: Select SUBJECT DETECTION ON (■ 158). The subject is poorly lit: Shoot in better light.