## Movie Menus



Name of the still literal with both and the still literal was a second with both the still literal was a second with the second was a second photography and movie shooting menus. Changes to these items in either menu also apply to the item in the remaining menu.

<u>,22</u>	MOVIE SETTING	
1⁄4	MOVIE SETTING LIST	186
	SHOOTING MODE	186
	MOVIE MODE	187
	BACKGROUND DEFOCUS MODE	188
	HIGH SPEED REC	189
	SELF-TIMER	190
	MEDIA REC SETTING	190
	HDMI OUTPUT SETTING	193
2⁄4	FIX MOVIE CROP MAGNIFICATION	194
	F-Log/HLG RECORDING	195
	DATA LEVEL SETTING	196
	PHOTOMETRY	196
	FLICKERLESS S.S. SETTING	196
	S MODE S MODE	197
	S MODE BOOST  ■ 15	197
	₽ ISO	197
	ZEBRA SETTING	198
	ZEBRA LEVEL	198
	MOVIE OPTIMIZED CONTROL 👄 🖢	199
3/4	REC FRAME INDICATOR	199
	TALLY LIGHT	200
	COOLING FAN SETTING	201
	EDIT/SAVE CUSTOM SETTING	201
	<b>AUTO UPDATE CUSTOM SETTING</b>	201
4⁄4	CUSTOM MODE SETTING	201
	★ WIRELESS COMMUNICATION	201

I.Q.	IMAGE QUALITY SETTING	
1⁄2	FILM SIMULATION	202
	MONOCHROMATIC COLOR	202
	₩ WHITE BALANCE	203
	M DYNAMIC RANGE	203
	TONE CURVE	203
	COLOR	203
	<b>SHARPNESS</b>	204
	🗯 HIGH ISO NR	204
<b>2</b> ⁄2	INTERFRAME NR	204
	<b>PERIPHERAL LIGHT CORRECTION</b>	205
	MOUNT ADADTOD CETTING	205