Optional Accessories


The camera can be used with the following optional accessories available from Fujifilm. For information on other accessories, see "Accessories from Fujifilm" (1288).

The AR-X100 Adapter Ring

1 Remove the front ring.



If you have trouble removing the front ring, grip the entire ring and rotate it as shown.



2 Attach the adapter ring as shown, with the projections facing out.



- Keep the front ring and lens cap in a safe place when not in use.
 - Attach the adapter ring AR-X100 before attaching LH-X100 lens hood, PRF-49/PRF-49S protector filter, or thirdparty filters.