# **Accessories from Fujifilm**

The following optional accessories are available from Fujifilm. For the latest information on the accessories available in your region, check with your local Fujifilm representative or visit https://fujifilm-x.com/support/compatibility/cameras/.

#### Rechargeable Li-ion batteries

**NP-W235**: Additional high-capacity NP-W235 rechargeable batteries can be purchased as required.

#### **Dual battery chargers**

**BC-W235**: The BC-W235 can charge up to two NP-W235 batteries at a time. At +25 °C/+77 °F, the batteries will charge in about 200 minutes. Using a device that supplies power with an outputs of 30 W or above reduces charging times to as little as 150 minutes.

### Remote releases

**RR-100**: Use to reduce camera shake. A third-party adapter that converts a female three-pin, Ø2.5 mm connector to a male three-pin, Ø3.5 mm connector is required for connection to the camera.

## Stereo microphones

MIC-ST1: An external microphone for movie recording.

## FUJINON lenses

**XF-/XC-series lenses**: Interchangeable lenses for use exclusively with the FUJIFILM X-mount.

FUJINON MKX-series lenses: Cinema lenses for the FUJIFILM X-mount.

## Macro extension tubes

**MCEX-11/16**: Attach between the camera and the lens to shoot at high reproduction ratios.

#### Teleconverters

**XF1.4X TC WR**: Increases the focal length of the compatible lenses by about 1.4×. **XF2X TC WR**: Increases the focal length of the compatible lenses by about 2.0×.

# Mount adapters

**FUJIFILM M MOUNT ADAPTER**: Allows the camera to be used with a wide selection of M-mount lenses.