-Focus and Exposure-

- Select focus mode **C** to vary focus with shot.
- To vary exposure with each shot, select **OFF** for **☑ BUTTON/DIAL SETTING > SHUTTER AE.**



Depending on such factors as aperture, sensitivity, and exposure compensation, exposure may not be adjusted automatically.