

## AF/MF SETTING

Adjust focus settings.

To display focus settings, press MENU/OK in the shooting display and select the **紐** (AF/MF SETTING) tab.





The options available vary with the shooting mode selected.

## **FOCUS AREA**

Choose the focus area for autofocus, manual focus, and focus zoom.