Basic Setup

4 Set the clock.

| DATE/TIME |
|---|
| GMT +1:00 BERLIN/PARIS |
| DD.MM.YY |
| MM/DD/YY 2023 . 12 . 31 12 : 00 AM 12h |
| YY.MM.DD |
| SET   NO |

**5 View information on the smartphone app.**

- The camera will display a QR code you can scan with your smartphone to open a website where you can download the smartphone app.
- Press **MENU/OK** to proceed to the next step.

APPLICATION
IMAGES CAN BE EASILY TRANSFERRED TO THE SMARTPHONE.
SCAN QR CODE TO ACQUIRE THE APP.
SET

Use the smartphone app to download pictures from the camera or control the camera remotely (📖 247).

6 Choose an AUTO POWER OFF TEMP.

- The selected setting determines the temperature at which the camera will turn off automatically.
- Press **MENU/OK** to exit to the shooting display.

AUTO POWER OFF TEMP.
STANDARD
HIGH
SET THE "AUTO POWER OFF TEMP." TO "HIGH" TO EXTEND THE RECORDING TIME. ONLY RECOMMENDED WHEN NOT HANDHELD OR WHEN USING TRIPOD ETC.
SET

7 Format the memory card (📖 332).

Format memory cards before first use, and be sure to reformat all memory cards after using them in a computer or other device.

If the battery is removed for an extended period, the camera clock will be reset and the language-selection dialog will be displayed when the camera is turned on.