CONSTANT SPEED ZOOM/FOCUS (Fn) OPERATION

Choose whether the function buttons on compatible power zoom lenses need only be pressed once to start and stop power focus or power zoom.

Option	Description		
START/STOP	The operation starts when the button is pressed and stops when		
SWITCH	it is pressed a second time.		
ACTIVE WHILE	The operation continues while the button is pressed and stops		
PRESSING	when the button is released.		

ZOOM RING ROTATE

Choose whether to reverse the rotation of the zoom ring on compatible power zoom lenses.

Options		
C CW (clockwise)	↑ CCW (counterclockwise)	

ZOOM/FOCUS CONTROL RING

Choose role played by the zoom/focus control ring on compatible power zoom lenses.

Options		
ZOOM	FOCUS	