- 5 Press MENU/OK to save changes to the selected item and return to the menu item list.
 Adjust additional items as desired.
- 6 Pressing **DISP/BACK** in the menu item list displays a confirmation dialog. Highlight **OK** and press **MENU/OK** to save the settings to the selected bank.

