DISP. CUSTOM SETTING

Choose the items shown in the standard indicator display.

- In shooting mode, use the DISP/BACK button to display standard indicators.
- 2 Press MENU/OK and select ☑ SCREEN SET-UP > DISP. CUSTOM SETTING in the ☑ (SET UP) tab.
- 3 Choose OVF or EVF/LCD.
- 4 Highlight items and press MENU/OK to select or deselect.
- 5 Press DISP/BACK to save changes.
- 6 Press DISP/BACK as needed to exit the menus and return to the shooting display.

Available Items

The items that can be displayed in the OVF or EVF/LCD monitor are as follows:

ltem	Default	
	OVF	EVF/LCD
FRAMING GUIDELINE		
ELECTRONIC LEVEL		
FOCUS FRAME	✓	✓
AF DISTANCE INDICATOR		
MF DISTANCE INDICATOR	✓	✓
HISTOGRAM		
LIVE VIEW HIGHLIGHT ALERT	_	
SHOOTING MODE	✓	✓
APERTURE/S-SPEED/ISO	✓	✓
INFORMATION BACKGROUND	_	✓
Expo. Comp. (Digit)		
Expo. Comp. (Scale)	✓	✓
FOCUS MODE	✓	✓