- 6 Adjust wireless LAN settings.
 - ACCESS POINT SETTING: See "Simple Access Point Connections" (1997) 264).
 - IP ADDRESS SETTING: See "Connecting Using an IP Address" (265).
- 7 After adjusting wireless LAN settings, select NEXT.





8 Name the communication setting profile.



9 Save the connection setting profile. Press MENU/OK.



10 Select CREATE NEW.

