| ò | SHOOTING SETTING | |
|-------------------------|--------------------------|-----|
| | SPORTS FINDER MODE | 140 |
| | PRE-SHOT ES 🔁 | 141 |
| | SELF-TIMER | 141 |
| | SAVE SELF-TIMER SETTING | 142 |
| 1/3 | SELF-TIMER LAMP | 142 |
| | INTERVAL TIMER SHOOTING | 143 |
| | INTERVAL TIMER SHOOTING | 144 |
| | EXPOSURE SMOOTHING | |
| | AE BKT SETTING | 144 |
| | FILM SIMULATION BKT | 145 |
| | FOCUS BKT SETTING | 145 |
| | MULTIPLE EXPOSURE CTRL | 145 |
| 2/3 | PHOTOMETRY | 145 |
| 2/3 | SHUTTER TYPE | 146 |
| | FLICKER REDUCTION | 147 |
| | IS MODE | 147 |
| | ISO | 148 |
| 3 / ₃ | ★ WIRELESS COMMUNICATION | 148 |

| ı | ₹ FLASH SETTING | |
|---|---|--------------------------|
| 1 | FLASH FUNCTION SETTING | 149 |
| | RED EYE REMOVAL | 149 |
| | TTL-LOCK MODE | 150 |
| | LED LIGHT SETTING | 150 |
| | COMMANDER SETTING | 151 |
| | CH SETTING | 151 |
| | | |
| | ™ MOVIE SETTING | |
| | | 152 |
| - | MOVIE MODE | |
| | MOVIE MODE FILE FORMAT | 152 |
| | MOVIE MODE FILE FORMAT FULL HD HIGH SPEED REC | 152 152 |
| - | MOVIE MODE FILE FORMAT FULL HD HIGH SPEED REC | 152 152 152 |
| | MOVIE MODE FILE FORMAT FULL HD HIGH SPEED REC | 152 152 152 152 |