言語/LANG.

Choose a language.

MY MENU SETTING

Edit the items listed in the MY (**MY MENU**) tab, a personalized custom menu of frequently-used photo menu options (📖 313).

MY MENU SETTING

Edit the items listed in the MY (**MY MENU**) tab, a personalized custom menu of frequently-used movie menu options (📖 313).