## Uploading Files via FTP

You can connect the camera to an existing FTP server and upload pictures via FTP.

## Connecting to FTP Servers

- Connecting via Wireless LAN ( 278)
- Connecting via Wired LAN (Ethernet) ( 281)

## Connecting via Wireless LAN

Connect to an FTP server via wireless LAN.

- 1 Select CREATE/EDIT CONNECTION SETTING > CREATE USING WIZARD in the network/USB setting menu and choose FTP TRANSFER.
- 2 Select CREATE NEW.
  - Choose SELECT FROM LIST to select from a list of existing connection setting profiles.
- **?** Press **MENU/OK** when prompted.



